Sonos Ace Ultra

Guides Sonos Ace Ultra

Overview

Sonos Ace Ultra is everything you want in your headphones. And then some.

- **Every note, just right.** Sonos-designed driver delivers deep bass, clear detail, and balanced sound you can custom-tune. Adaptive EQ ensures the sound is tuned based on how the headphones fit.
- **Tune to the pack.** Up to 3x more Active Noise Cancellation than Sonos Ace. So hear what's around you with Aware Mode.
- **Talk to the world better.** Hear your friends and Sonos voice assistant as well as Sonos. Get the most from Ace Ultra with Active Voice Cancellation.
- **Part of the Sonos system.** Play music, TV, your local library, even what's for dinner first. Ace Ultra using the app you're already listening to for your speakers.
- **Comfort and durability.** Plush ear cushions, memory foam ear cups, and an adjustable headband create a soft, secure fit.

Controls, lights, and ports

1	**Control Key**	**Playback** • Play/Pause: Press once to pause or resume streaming content • Track Changes • Previous Track: Press twice quickly • Next Track: Press and hold • Hold down Play and use or down Slide and hold to quickly change the volume **Setup** • When you link your headphones to your system, press and hold to swap audio with nearby compatible speakers
2	**Noise Control/Voice Control**	**Noise Control** Press to switch between Active Noise Cancellation and Aware Mode. Note: In the Sonos app, you can change which Noise Control options Ace Ultra switches between. **Voice Control** Press and hold to activate your device voice assistant, such as Siri or Sonos. Tap for more options when Ace Ultra is in use.
3	**Status light**	Indicates headphone charging status. Blue/purple connection, and playback product updates and errors. Colors will reflect your custom-tuning Sound Profile.
4	**Power Bluetooth**	**Power on/off** • Press and hold (about 1 second) to power on your headphones. You'll hear a tone when they're ready to pair. • Press and hold (about 3 seconds) to power off. You'll hear a tone as they power off. **Bluetooth pairing** • Press and hold (about 5 seconds) to enter pairing mode. You'll hear a tone when they're ready to pair. Make sure that the Bluetooth device turned on and in the Bluetooth menu. • Go to the device's Bluetooth settings and select your headphones from the list of discovered devices. **Transfer between devices** To transfer your Sonos headphones, they automatically connect to the platform or most recently connected Bluetooth device if Bluetooth is turned on. **Factory reset** Press the **Select** and **Up** buttons Ace Ultra clear all the registration with the app settings, changes, and personalized Sound. 1. Make sure your Sonos Ace Ultra is turned on. 2. Press and hold the **Select** and **Up** buttons. 3. Release the buttons when you hear a tone. 4. The status light will flash white when your headphones have been factory reset. **Note:** Some Sonos Ace Ultra functionality may be unavailable if you pair with a Bluetooth device when you've just done a factory reset.
5	**USB-C port**	**Charging** Use the included cable to connect a USB-A™ or USB-C™ power USB-C power supply. 7.5 W minimum is required. You can plug your headphones into an active Sonos One or Sonos Era 300 speaker to charge.

Adjust the fit

Sonos Ace Ultra are tuned to extensive wear testing, with thoughtful consideration for different head shapes. Ear cushions and headband are designed to provide a comfortable, secure fit for most users.

The headphones are designed to evenly distribute and reduce pressure to better hold the ear up, an integrated memory foam cushion for ample support in headband and made of exceptional acoustic mesh.

- Make sure your headphones are powered on and worn correctly.
- Before you put them on, make sure each ear cup is in the correct position. The inside of the ear cup is the side of the ear cup with the inside of the right ear cup. The side is also a marking letter: L for left ear cup and R for right ear cup. Ear cups are labeled on the inside.

Ear cushions are easily replaced if they wear out over time. Each cushion is securely held in place by magnets and can be removed by pulling it off.

To remove and replace your cushion, here are some things to keep in mind:

- Make sure both cushions are in the correct position, such as the correct side, for the first time.
- Before trying to pull a cushion off, make sure you do not start to make out for the of tear and damage cushions.
- Ear cushions will automatically snap into place.

Earbuds pairing

Sonos Ace Ultra connect wireless over Bluetooth device when powered on after a factory reset.

To connect your Sonos Ace Ultra to a Bluetooth device, turn Bluetooth is enabled on the device you want to pair. Then, put your headphones in pairing mode. Your Sonos Ace Ultra will automatically connect to the last Bluetooth device it was paired to, provided that the device is in range and Bluetooth is turned on.

If you're pairing while streaming from Ace Ultra, hold the button pair the power down sound file sound.

If you're pairing while Sonos Ace Ultra off on your head, hold the button until the status light starts blinking white.

To connect to a device you've already paired with, go to the Bluetooth settings and select your Sonos headphones from the list of devices.

- If you're connecting while streaming Sonos Ace Ultra, you'll hear a sound confirming that your Sonos Ace Ultra are connected.
- Once connected, the status light on Sonos Ace Ultra will change to solid blue and your device's Bluetooth settings will show your headphones as connected.

Light	Description
Solid white	Powered on, not connected to a Bluetooth device
Solid blue	Powered on, connected to a device via Bluetooth
Blinking blue	Powered on, searching for a Bluetooth device

Multipoint

Multipoint lets your Sonos Ace Ultra's Bluetooth devices and automatically switch between audio sources. You can have Bluetooth is enabled of both of your devices.

To set up:

1. Go to **Settings** ⓘ.
2. Choose Sonos Ace Ultra under **Headphones**.
3. Turn **Bluetooth**. Then select **Multipoint**.
4. Select **Multipoint** at the device. Turn it on your Sonos Ace Ultra Settings.

Bluetooth pairing

Sonos Ace Ultra connect wireless over Bluetooth device when powered on after a factory reset.

To connect your Sonos Ace Ultra to a Bluetooth device, turn Bluetooth is enabled on the device you want to pair. Then, put your headphones in pairing mode. Your Sonos Ace Ultra will automatically connect to the last Bluetooth device it was paired to, provided that the device is in range and Bluetooth is turned on.

If you're pairing while streaming from Ace Ultra, hold the button pair the power down sound file sound.

If you're pairing while Sonos Ace Ultra off on your head, hold the button until the status light starts blinking white.

To connect to a device you've already paired with, go to the Bluetooth settings and select your Sonos headphones from the list of devices.

- If you're connecting while streaming Sonos Ace Ultra, you'll hear a sound confirming that your Sonos Ace Ultra are connected.
- Once connected, the status light on Sonos Ace Ultra will change to solid blue and your device's Bluetooth settings will show your headphones as connected.

Light	Description
Solid white	Powered on, not connected to a Bluetooth device
Solid blue	Powered on, connected to a device via Bluetooth
Blinking blue	Powered on, searching for a Bluetooth device

Power and charging

Use the included cable to connect a USB-A™ power or USB-C™ power USB-C power supply. 7.5 W minimum is required.

You can plug your Sonos Ace Ultra into an active Sonos One or Sonos Era 300 speaker to charge.

Note: Charge your Sonos Ace Ultra at ambient temperatures between 41° and 104°F (5° and 40°C).

Low battery

When your battery level reaches 10% power, you'll hear a tone and the status light will flash orange.

Light	Description
Flashing orange	Between 5% and 10% battery remaining

Charging

Charge your Sonos Ace Ultra with power.

1. Put the ear cups down and fold your headphones are plugged in and charging.
2. The charge light will turn **solid green** when your headphones are plugged in and now charging.

Light	Description
Solid orange	Plugged in and charging normally. Below 100% charge
Solid green	100% battery. You can unplug your headphones.
Flashing red	Charging error. Unplug your headphones from power.

Rapid charging

When your Sonos Ace Ultra reaches 10% power or lower, rapid charging quickly recharges them to give you 3 hours of playback in just 3 minutes.

Use the included USB-C to USB-C cable and a compliant USB-C power supply not included to charge your headphones.

- 3 Min = 3 Hrs 0 minutes
- 1 Min = 1 Hr 30 min. Sonos Ace Ultra
- **Note:** Rapid charging requires an ambient temperature between 59°F and 95°F (15°C and 35°C). Rapid charge Sonos Ace Ultra charges at standard speed.

Linking to your system

You can link Sonos Ace Ultra to your system, and then use the Sonos app to play content to them. You can also switch between playing audio on your headphones and your Sonos speakers. To turn on Sonos Voice, or Voice. To use Headphones. Go Again to move the sound back to your speakers.

Make sure your Sonos Ace Ultra are powered on. Sonos Ace Ultra will turn on when you put on or take out of the headphones carrying case, and the headphones will automatically connect to the last Sonos system you were listening to.

1. Go to the Sonos app.
2. Select **Settings** then select your Sonos Ace Ultra.
3. Select a link to your system. This will turn on TV Audio Swap with an compatible soundbars in your system.

Note: Linking to your system disconnects your headphones from any Bluetooth devices they're connected to. Sonos Ace Ultra can't connect to your headphones to stream or receiving call automatically, but an ideal Bluetooth device is connected to Sonos Ace Ultra.

Receive a call

Sonos Ace Ultra connect to the device to receive any call. You'll hear a tone when the call connects successfully.

Note: If you want to receive a call on your headphones to answer an incoming call automatically, turn on ideal Bluetooth device is connected to Sonos Ace Ultra.

End a call

Press the Control Key to end a call on your headphones. You'll hear a tone when the call is disconnected.

TV Audio Swap

TV Audio Swap allows you to move TV audio from a compatible Sonos soundbar to Sonos Ace Ultra. Set it up and Listen to Sonos Ace Ultra to watch and listen together.

Once it's set up, press and hold the Control Key on your right ear cup to switch to your headphones or swap it back to your soundbar. Your soundbar will play a tone to let you know when it's ready to stream to Sonos Ace Ultra.

Make sure your Sonos Ace Ultra are powered on. Sonos Ace Ultra will turn on when you put on or take out of the headphones carrying case, and the headphones will automatically connect to the last Sonos system you were listening to.

1. Go to the Sonos app.
2. Select **Settings** then select your Sonos Ace Ultra.
3. Select a link to your system. This will turn on TV Audio Swap with an compatible soundbars in your system.

Note: Linking to your system disconnects your headphones from any Bluetooth devices they're connected to. Sonos Ace Ultra can't connect to your headphones to stream or receiving call automatically, but an ideal Bluetooth device is connected to Sonos Ace Ultra.

Voice control

If your Sonos Ace Ultra is connected to a Bluetooth device that has a built-in voice assistant, you can activate it by pressing and holding the Control Key on your right ear cup. Sonos Ace Ultra will switch to your device's voice assistant. You'll hear a tone when it's ready to listen.

Wear detection

Sonos Ace Ultra uses sensors in the ear cups to detect if you're wearing them. When you take them off, Sonos Ace Ultra will pause playback. When you put them back on, playback resumes.

Wear detection is turned on by default. With wear detection on, Sonos Ace Ultra will also: • Pause audio if you remove the Sonos Ace Ultra from the ear cups to keep music playback and notifications private. • Switch to your Sonos speakers when you take off your Sonos Ace Ultra. • Switch to your Sonos Ace Ultra when you put them on. You can turn off wear detection at any time in the Sonos app.

Phone calls

Sonos Ace Ultra will turn on when you put on the headphones carrying case, and the headphones will automatically connect to the last Sonos system you were listening to.

Answer a call

Press the Control Key to answer a call on your headphones. You'll hear a tone when the call connects successfully.

Note: If you want to receive a call on your headphones to answer an incoming call automatically, turn on ideal Bluetooth device is connected to Sonos Ace Ultra.

End a call

Press the Control Key to end a call on your headphones. You'll hear a tone when the call is disconnected.

Product settings

Use the Sonos app to adjust product settings for Sonos Ace Ultra.

1. Go to **Settings** ⓘ.
2. Choose Sonos Ace Ultra under **Headphones**.

Settings	Description
Name	Change the name of your Sonos Ace Ultra. This name will show up in Bluetooth menus and the microphone list app.
Status	Displays battery percentage and firmware version.
Sonos Controls	My accounts Controls of Sonos Control • Active Voice Cancellation: Significantly reduces background noise. Make sure your Sonos Ace Ultra fit snugly to get the most out of this mode. • Aware Mode: Sonos Ace Ultra uses the microphones to let in the world around you so you can hear your surroundings without removing your headphones. • Off: You can turn off Active Noise Cancellation and Aware Mode if Sonos Ace Ultra can switch your sound environment quickly and battery. Sonos Ace Ultra will remember your last setting and switch between it and Off when you press to switch.
Voice Control	Choose which voice assistant you want to use with your headphones. Sonos Ace Ultra will switch between it and your Sonos voice assistant when you press and hold the Control Key on your right ear cup. Sonos Ace Ultra will switch between it and your Sonos voice assistant when you press and hold the Control Key on your right ear cup. Sonos Ace Ultra will switch between it and your Sonos voice assistant when you press and hold the Control Key on your right ear cup.
EQ	Make adjustments to EQ. • Bass • Treble • Balance Loudness Trupio Head Tracking spatial audio
Head tracking	Turn on or off to use Sonos Intelligent Motion Processing with Dolby Head Tracking and Dolby Atmos content. For Dolby Head Tracking, Sonos headphone commands you to hyperrealistic sound with different elements of the soundstage that remain anchored to your device, even as you move your head.
System	• Auto: Will switch between the TV and your Sonos system. • Sonos Soundbar: Always connect to your Sonos soundbar. • Off: Always connect to your Sonos system. • Head tracking: Uses Wi-Fi. Turn on or off when streamed from your Sonos system. Head tracking is turned off by default. Head tracking can't be used with Trueplay tuning. Make sure you're using the latest version of the Sonos app. Then, update your Sonos Ace Ultra to the latest software. • Trueplay tuning: Uses Wi-Fi. Turn on or off when streamed from your Sonos system. Trueplay tuning is turned off by default. Trueplay tuning can't be used with Head tracking. Make sure you're using the latest version of the Sonos app. Then, update your Sonos Ace Ultra to the latest software. Trueplay tuning is turned off by default. Trueplay tuning can't be used with Head tracking. Make sure you're using the latest version of the Sonos app. Then, update your Sonos Ace Ultra to the latest software.
Bluetooth	Manage multipoint, pairing preferences and devices, and set an in-ear connection to use your Bluetooth device.
Battery	• Charging: Change how you or headphones charge with rapid charging. • Power Saving: Change how your headphones save battery with power saving. Power saving is turned off by default.
Hardware Controls	• Voice Control: Select the button you want to cycle through when pressing and holding the Control Key. • Wear Detection: Turn on or off playback control and power when you put on or take off your headphones.
About	• Find product model number. • Check for software updates and see the current software version.

Specifications

Audio

Drivers	Custom-designed 40 mm dynamic driver in each ear cup
Microphones	10 microphones for voice control and voice targeting
Spatial audio	Stream spatial audio content from supported services and devices.
Lossless audio	Enjoy lossless audio over Bluetooth with a mobile device that supports aptX Lossless, such as a OnePlus 11 or Xperia 1 V.
Noise control	Active Noise Cancellation blocks external noise sounds. Aware mode lets pressure sound when you choose.
Head tracking	Sonos Intelligent Motion Processing with Dolby Head Tracking. Enable this feature in the Sonos app.
TV Audio Swap	Press the Control Key to swap sound from a compatible Sonos soundbar to Sonos Ace Ultra and back again.
Dolby Atmos	Requires a compatible device and a streamable content.
Adjustable EQ	Use the Sonos app to adjust bass, treble, and balance.

Details & Dimensions

Dimensions	• Height: 7.68 in (195 mm) • Width: 6.9 in (175 mm) • Depth: 3.11 in (80 mm)
Weight	0.73 lbs (331 g)
Colors	• Black • Soft White • Hyper • Sunset
Finish	• Matte • Stainless steel • Hyper leather
LED	Light on the bottom of the left ear cup indicates connection status

Controls

Control Key	• Slide up and down for volume control • Press once to play/pause • Press twice to skip a track • Press Sonos Voice to play previous track. • Press once to answer a call • Press and hold to decline a call.
Noise Control/Light ear cup	• Press to switch between the Noise Control modes you've selected for your headphones in the Sonos app: Active Noise Cancellation or Aware Mode. • Press and hold to activate the voice assistant.
Power/Bluetooth left ear cup	• Press and hold the Power/Bluetooth button (about 1 second) to power on your headphones. • Press and hold the Power/Bluetooth button (about 3 seconds) to turn your headphones into Bluetooth pairing mode and power on or turn off.

Power & Connectivity

Bluetooth	Bluetooth 5.3 supports audio streaming from any Bluetooth-enabled device.
Battery (rechargeable)	Up to 30 hours of playback with ANC enabled Replacement: You can replace the battery in your headphones. Disposal: Check with your local waste or recycling company to determine the proper disposal instructions for your area.
Charging	Use the included cable to connect a USB-A™ certified or USB-C™ certified USB-C power supply. 7.5 W minimum is recommended. Rapid charge provides 3 hours listening time in 3 minutes from 0%. Full charge takes 3 hours from 0% with a 15 W charger. **Note:** The included cable is for charging only. It doesn't support audio or data, and the 10 feature to get the maximum charging speed.
Ports	• Supports USB-A™ charger and USB-C™ • Used to play content from the app and easily add compatible speakers.
Operating temperature	32°F to 104°F (0°C to 40°C)
Charging temperature	41°F to 104°F (5°C to 40°C)
Rapid charging temperature	59°F to 95°F (15°C to 35°C)

What's in the box?

Product	Sonos Ace Ultra
Travel case	Ultra-compact soft carrying case
USB-C to USB-C cable	1.5 ft (0.5 m)
USB-C to 3.5 mm cable	5 ft (1.5 m) **Note:** Sonos Ace Ultra is not compatible with third-party cables.
Documentation	Quickstart Guide and legal/safety information

Requirements

Audio source	Supported Bluetooth device, such as a smartphone
Power source	Use the included cable to connect a USB-A™ certified or USB-C™ certified USB-C power supply. 7.5 W minimum is recommended.

Important safety information

- Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.
- Do not use this product near water—for example, near bathtubs, wash bowls, kitchen sinks, or laundry tubs; in a wet basement; or near a swimming pool; and the like.
- Keep the charging cable from being pulled on or pinched, particularly at plugs, convenience receptacles, or the point where they exit from the product.
- Only use attachments/accessories recommended by the manufacturer, such as the charging cable included in the box. Using the charging cable provided (or one with USB-C to USB-C cable) to charge this product.
- Do not expose this product to excessive dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the product.
- Refer all servicing to Sonos qualified service personnel.
- Warning: The units or accessories: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. Do not expose this product to dripping or splashing.
- Do not use this product while cycling, driving, or engaged in any other activity where your full attention is required. Doing so may result in an accident.